

# RAPTOR Bridge - Module for battery service connection

## RAPTOR BRIDGE


Normally, when the motor of the camper is turned on, the motor battery and the service battery are connected in parallel by the internal parallel relay to the service unit so that they both are charged during driving.

However, this connection is not improved, limiting the current flow and extending the charging time as a result.

RAPTOR Bridge is able to connect the two batteries in parallel when the motor is turned on, excluding the vehicle's control unit, this allows a greater current flow to the services battery for faster recharging, avoiding the passage of high flows of current in the centraline to prevent the risk of damage. When the motor is switched off, RAPTOR Bridge automatically restores the original connection of the batteries to the vehicle's control unit. The installation of RAPTOR Bridge does not invalidate the vehicle warranty.



### Original connection



### Optimized connection with RAPTOR Bridge

